

Shower Timers

ECOSAVERS[®]

Shower Timers

Duck, Frog and Drop shaped



EcoSavers® Shower Timers

Duck, Frog and Drop shaped

ECOSAVERS®



Shower Timers from EcoSavers® are innovative new products to educate children and adults alike to learn about saving water and energy.

Easy set the minutes and seconds you want to shower and after the set time, the timer will beep as a sign to stop showering. Limit the time you shower and save water and energy, every day time and time again.

These products with digital countdown timers and alarm can easily be mounted on the shower wall by the integrated suction cup.

Start saving water and energy today with the EcoSavers® Shower Timers!

Choose between 3 different exciting models.



Drop shape



Duck shape



Frog shape



SPECIFICATIONS

| | |
|--------------|--|
| Time | 1 sec. – 99 min / 59 sec. |
| Buttons | 1. Minute 2. Seconds 3. Start/stop |
| Reset | Push minute and second buttons together |
| Battery Type | LR44 (AG 13) included |

SIZES

| | |
|------------|--|
| Duck shape | 120 x 105 x 25 mm (included suction cup) |
| Frog Shape | 120 x 95 x 25 mm (included suction cup) |
| Drop Shape | 75 x 60 x 20 mm (included suction cup) |